

PARTS GUIDE

Using the Parts Guide below, check to make sure all parts are included in the box.
If parts are missing or damaged call 1-888-830-1326.
PLEASE DO NOT RETURN THIS PRODUCT TO THE STORE.

Before installing your fan, record the following information for your records and warranty assistance.

Model Name _____

Catalog No. _____


Serial No. _____

Date Purchased _____

Where Purchased _____

Fan Parts

(Not Drawn to Scale)



Missing / Broken Parts:
Call 1-888-830-1326

Fan does not work:


1. Reference the Trouble Shooting guide in your Instruction Manual.
2. Call your Local Service Center.
3. Call Technical Support at 901-248-2222.

For additional information on:

Hunter Products • Trouble Shooting
Dealer Location • Service Center Locator
Call 1-800-448-6837
www.hunterfan.com

Hardware

(Drawn to Scale)



Part List

		Model #	28425	28424
		Asm. Dwg. #	94471-01	94493-01
		Finish	Oil Rubbed Bronze	Oil Rubbed Bronze
Item #	Item Name	Qty	Part #	
1	* Hanging System Kit	1	94423-57-000	94423-57-000
2	Ceiling Plate	1	74704-01-000	74704-01-000
3	Canopy	1	93850-01-308	93850-01-308
4	Canopy Trim Ring	1	93936-01-308	93936-01-308
62	Canopy Screw	3	74510-03-247	74510-03-247
64	Wood Screw	2	06512-01-232	06512-01-232
65	Wood Screw	2	03144-03-232	03144-03-232
68	Flat Washer	4	06301-01-232	06301-01-232
71	Mounting Isolator	4	64724-01-000	64724-01-000
7	Hanger Ball / Downrod Assembly	1	74290-21-308	74290-21-308
12	Adapter Cover	1	84614-01-308	84614-01-308
28	Switch Housing	1	93464-01-308	93464-01-308
29	Switch Housing Cover	1	93973-01-308	93973-01-308
44	Blade Iron Set	1	74941-05-308	93463-05-308
46	Blade Set	1	74438-94-000	75147-08-000
47	Blade Iron Armature Screw	10	64403-01-247	64403-01-247
60	* Hardware Kit	1	94471-00-860	94493-00-860
66	Blade Grommet	15	05989-01-000	05989-01-000
67	Blade Assembly Screw	15	63730-01-247	63730-01-247
69	#6-32 x 3/8" Screw	6	74506-03-247	74506-03-247
70	Wire Nut	4	05172-01-000	05172-01-000
216	#6-32 x 1/2" Screw	2	74506-04-247	74506-04-247
75	Balancing Kit	1	07570-01-000	07570-01-000
79	Allen Wrench	1	64801-01-000	64801-01-000
86	Remote Control Receiver	1	85662-01-000	85662-01-000
87	Remote Control Transmitter	1	85752-01-000	85752-01-000
88	Remote Control Cradle	1	85785-01-000	85785-01-000
145	Light Fixture	1	84756-01-308	84756-01-308
148	Bottom Cap	1	64709-01-308	64709-01-308
149	Finial	1	64711-01-308	64711-01-308
150	Globe/Shade	1	93969-03-000	93969-03-000
248	Tiffany Bowl	1	94470-01-308	94492-01-308





GUÍA DE PIEZAS


Use la Guía de Piezas de abajo para verificar que todas las piezas estén incluidas en la caja.

Si alguna pieza falta o está dañada, llame al teléfono 1-888-830-1326.

POR FAVOR NO DEVUELVA ESTE PRODUCTO A LA TIENDA DONDE LO COMPRÓ.

Antes de instalar su ventilador, anote la información siguiente para sus archivos y asistencia con la garantía.

Piezas del ventilador (no dibujadas a escala)



Nombre del modelo _____

No. de catálogo _____

No. de serie _____

Fecha de compra _____


Lugar de compra _____

Si alguna pieza falta o está rota:
Llame al teléfono 1-888-830-1326

- Si el ventilador no funciona:**
1. Consulte la guía de localización de fallas en su manual de instrucciones.
 2. Llame a su centro local de servicio.
 3. Llame al teléfono 901-248-2222 para obtener asistencia técnica.

Para informaciones adicionales acerca de:
Productos Hunter • Localización de fallas
Localización de distribuidores
Localización de centros de servicio
Llame al teléfono 1-800-448-6837
www.hunterfan.com

Materiales (dibujados a escala)



Lista de piezas

		No. del modelo	28425	28424
		No. del dibujo de ensamblaje	94471-01	94493-01
		Acabado	Bronce mate	Bronce mate
No. del ítem	Nombre del ítem	Cantidad	No. de la pieza	No. de la pieza
1	* Equipo de sistema de colgar	1	94423-57-000	94423-57-000
2	Placa del techo	1	74704-01-000	74704-01-000
3	Campana	1	93850-01-308	93850-01-308
4	Anillo decorativo de la campana	1	93936-01-308	93936-01-308
62	Tornillo de la campana	3	74510-03-247	74510-03-247
64	Tornillo para madera	2	06512-01-232	06512-01-232
65	Tornillo para madera	2	03144-03-232	03144-03-232
68	Arandela plana	4	06301-01-232	06301-01-232
71	Aisladore	4	64724-01-000	64724-01-000
7	Bola de suspension / Conjunto del tubo de soporte	1	74290-21-308	74290-21-308
12	Cubierta del adaptador	1	84614-01-308	84614-01-308
28	Conjunto de la caja del interruptor	1	93464-01-308	93464-01-308
29	Cubierta de la caja del interruptor	1	93973-01-308	93973-01-308
44	Equipo de herrajes para la paletas	1	74941-05-308	93463-05-308
46	Equipo de paletas	1	74438-94-000	75147-08-000
47	Tornillo para los herrajes de las paletas	10	64403-01-247	64403-01-247
60	* Equipo de herrajes	1	94471-00-860	94493-00-860
66	Arandela de caucho, de paleta	15	05989-01-000	05989-01-000
67	Tornillo, de conjunto de paleta	15	63730-01-247	63730-01-247
69	Tornillo #6-32 x 3/8"	6	74506-03-247	74506-03-247
70	Tuerca para alambre	4	05172-01-000	05172-01-000
216	Tornillo, #6-32 x 1/2"	2	74506-04-247	74506-04-247
75	Equipo equilibrador	1	07570-01-000	07570-01-000
79	Llave, Allen	1	64801-01-000	64801-01-000
86	Parte del receptor	1	85662-01-000	85662-01-000
87	Transmisor del control remoto	1	85752-01-000	85752-01-000
88	Soporte del control remoto	1	85785-01-000	85785-01-000
145	Conjunto de luces	1	84756-01-308	84756-01-308
148	Placa de cubierta	1	64709-01-308	64709-01-308
149	Caperucha	1	64711-01-308	64711-01-308
150	Globo / Pantalla	1	93969-03-000	93969-03-000
248	Tazón de fuente De Tiffany	1	94470-01-308	94492-01-308

